



For proper contact, it is critical that no washers be placed between the battery cable lugs or between them and the FW-SBUS. The order should be as shown (starting from the bottom: lugs, flat washer, and lock washer, secured to the FW-SBUS with a shunt bus bolt).